

SPARE PARTS LIST Soap dispenser DESIGN 282

Απ. Νο.	Spare part
10837	Security key for housing
28202	Square key for housing
10836	Soap container
10845	Tube with nozzle, silicone
10850	Control box / sensor (for soap dispenser with LED)
10842	Control box / sensor (for soap dispenser without LED)
10838	Plastic push bar (for dosage)
10844	4,5 Vdc transformer f/connection to 230 Vac – for soap dispenser without LED
10888	6 Vdc transformer f/connection to 230 Vac – for soap dispenser with LED

