



SPARE PARTS LIST

Soap dispenser DESIGN 295

Art. No.	Spare part
10837	Security key for housing
28202	Square key for housing
10870	Soap container
67137	Pump with nozzle
10887	Control box / sensor
10888	6 Vdc transformer f/connection to/230 V
10846	Base plate
10853	Housing

