



# SPARE PARTS LIST

## COLUMN 3196-3198

Pos. no.	Art. No.	Spare part
1	51753	Faucet, complete (for batteries)
2	51710	End piece
3	51712	Silicone ring
4	51714	Holder for LED printed circuit board and sensor
5	51716	Rubber gasket (top)
6	51718	Rubber gasket (bottom)
7	51720	Nylon disc
8	51722	Nut
10	51654	Nozzle for disinfectant
11	51653	Hose 700mm
12	51754	Control box (for batteries)
13	51752	Pump and hose
15	51755	External battery box
16	28208	Complete lock (silver)
	28209	Complete lock (black)
	28202	Square key, black polyamide
21	31907	Drip tray
22	31920	Clip



NB: Please note, the position numbers in the above spare parts list refer to the numbers listed in the component overview in the installation manual.