



SPARE PARTS LIST

AIR TAP

Model 370 / 372



Pos. no.	Art. no.	Spare Part
3 + 4	51607	Outlet nozzle with sensor
5	51665	Silicone holder
6	51648	Plastic holder for LED terminal board
7	51608	LED terminal board
8	51620	End piece "AIR TAP"
9	51602	TAP with cable, deck-mounted (120cm) (incl. art. 1-14+33,34)
9	51604	TAP with cable, wall-mounted (120cm) (incl. art. 1-14+33,34)
10	51705	Bushing
11	51706	Gasket small
12	51700	Gasket big
13	51697	Disc, stainless
14	51696	Nut
15	51622	Flex hose (45 cm)
15	51623	Flex hose (150 cm)
16		Clamp for flex hose
21	51605	Timer 230V (60Hz)
21	51614	Timer 120V (50Hz)
23		Cap for mounting of hose (motor part)
25	51600	Motor 230V (60Hz)
25	51601	Motor 120V (50Hz)
26	51612	Heating element 230V (60Hz)
26	51613	Heating element 120V (50Hz)
31	51615	Filter holder + carbon filter
	51617	Carbon filter