

SPARE PARTS LIST



SOAP TAP, deck-mounted

Model: 376, 380, 476, 480, 736, 740



| POS. NO. | ART. NO. | SPARE PART |
|----------|----------|---|
| 1 | 51658 | TAP "SOAP" |
| | 51657 | TAP "FOAM" 1m |
| 2 | 51659 | End piece "FOAM" |
| | 51637 | End piece "SOAP" |
| 3 | 51647 | LED terminal board |
| 4 | 51648 | Holder for LED terminal board |
| 5 | 51666 | Sensor silicone liner |
| 6 + 7 | 51656 | Sensor and holder for nozzle (lower part) |
| 8 | | Holder for nozzle (upper part) |
| 9 | 51705 | Bushing Ø 34 mm with thread |
| 10 | 51706 | Gasket for bushing |
| 11 | 51697 | Disc |
| 12 | 51700 | Gasket big |
| 13 | 51696 | Nut |
| 15 | 51655 | Nozzle for FOAM |
| 16 | 51654 | Nozzle for SOAP |
| 18 | 51649 | Soap tube FOAM, 100 cm |
| | 51653 | Soap tube SOAP, 70 cm |
| 19 | 51630 | Control box |
| 20 | 51641 | Mounting plate for control box and soap container |
| 21 | 51610 | Tools for fastening of nut |
| 22 | 51634 | Soap container 1.5L |
| | 51643 | Soap container 3L |
| 23 | 51650 | Pump FOAM |
| 24 | 51635 | Pump SOAP |
| 25 | 10888 | AC-adapter |