



SPARE PARTS LIST

BJÖRK waste bin 18 l

3320/3325/3330



| Pos. No. | Art. No. | Spare part |
|----------|----------|------------------------------|
| 5 | 28200 | Frame for lock cylinder |
| 6 | 28201 | Lock cylinder for square key |
| 7 | 28202 | Square key, black, polyamide |
| 8 | 28207 | Plastic washer for lock |
| 9 | 33200 | Front cover |
| 10 | 33205 | Back plate |
| 11 | 33210 | Ring holder for plastic bag |
| 12 | 33715 | Locking pawl |
| 13 | 33725 | Spring for lock |