



SPARE PARTS LIST

Hand Dryer BJÖRK 3000+3002+3006

Pos. No.	Art. No.	Spare part
1	50700	Housing – white (RAL 9003, gloss 60)
	50710	Housing – black (RAL 9005, gloss 10)
	3070	Top plate, Negro Ingo
	3072	Top plate, Bianco Male
	3074	Top plate, Grigio Londra
	3076	Top plate, Birch
	3078	Top plate, Geo White
	3080	Top plate, Oslo
2	50717	Terminal board, fixed plate
3		Tensile relief clamp
4		Terminal block
5		Earth screw
6		Shock absorber
7+21	50535	Fan housing (top+bottom)
8		Rubber gasket for fan housing (large)
9	50520	Motor, 230 V, 700 W
	50515	Carbon for motor
10	50517	Rubber gasket for fan housing (small)
11	50505	Heating element, 230 V, 900 W
12	50516	LED unit, ErP, 4-pole
	50720	Light guide
13	50527	Air outlet
14		Mounting bracket for sensor
15	50504	Sensor w/connector, 6 wire, ErP
16		Mounting bracket for fan housing
17	50715	Base plate
18	50508	Potentiometer
		(=adjusting screw, motor and heat), 3 pole, ErP
19		Mounting bracket for adjusting screw
20	50725	Björk timer w/connector for sensor and adjusting screw, ErP
22	50713	Housing screws (2 pcs.)
23	50020	Allen key for housing screws
	50580	Holder incl. carbon particle filter
	50582	Replacment carbon particle filter



reddot award 2015
winner